



Trijicon® RMR®cc Quick Reference Card

POWER ON: Press either button. (RMRcc wakes up in automatic mode.)

Press/release '+' button to increase brightness & enter **MANUAL MODE**.
Press/release '-' button to decrease brightness & enter **MANUAL MODE**.

Press both buttons to return to return to **AUTOMATIC MODE**.
Press both buttons & hold >3 secs to **POWER OFF**.


Note: Dot automatically adjusts to ambient lighting after **16.5 hours**.

REVISION 8

1 IN

Instructions: Print actual size, cut out, fold 1X to produce a 3"x5" card for pocket or range bag.
1" and 1 cm grids provided to estimate group sizes.

Trijicon® RMR®cc Quick Reference Card



MANUAL MODE has 8 brightness settings.

AUTOMATIC MODE covers settings 3-7 depending on ambient light.

Battery is a CR2032 3V DC Lithium. Install negative side "-" facing down.
Dot will become dimmer as the battery gets low.

Turn **Adjustment screws** in the direction to move impacts, 1click=1MOA

25 yds: 6.5 MOA=1.7" / 3.25 MOA=0.9"

10 yds: 6.5 MOA=0.7", 3.25 MOA=0.3"

Torque Optic Screws until seated, then secure.

Clean with fresh water and clean cloth, not alcohol, TCE or acetone

Footprint: RMRcc

Trijicon Customer Service: www.trijicon.com (800) 338-0563

DISCLAIMER: Information adapted from OEM sources, but is not verified nor endorsed.
User is advised to verify any content herein with manufacturers documentation.

1 CM