



## Holosun 509T X2

**Power ON:** Shake sight or press either brightness button

**Power OFF:** Press "+" and "-" simultaneously to turn power and motion sensor off (**Shake Awake™** (\*) is disabled)

Press "-" 3 sec, to switch from Circle+Dot(\*), Dot, and Circle

Press "+" 3 sec, to switch from Automatic(\*) to Manual to Lockout

**Solar Fail Safe™** provides dual power (solar and internal)

\*default

GENERAL PURPOSE GRID: 1.00"

Layout / Design llando88@gmail.com 2021. Unlimited copy and distribution permitted. **REV 9**

## Holosun 509T X2



### 10 daylight and 2 NV brightness settings.

Your selected Manual Brightness is ☐ clicks down from FULL BRIGHT. Battery is a **CR1632**. Reticle blinks if the battery is low (2.2 V).

Insert new battery "+" side **DOWN**.

**Adjustment screws** move center of impact U/D, R/L. 1click = 1MOA

**25 yds:** 32MOA=8.4" 2MOA=0.5" **10 yds:** 32MOA=3.4" 2MOA=0.2"

6-32 T10 Plate screws=15 in-lbs+blue threadlocker; clamp=20 in lbs

Clean with lens cleaner, **NO** alcohol or acetone

Footprint: RMR / Titanium body / 1 Meter IPX7 waterproof fogproof

[www.holosun.com](http://www.holosun.com) [warranty@holosun.com](mailto:warranty@holosun.com) (909) 594-2888

Instructions: Cut on dotted lines / fold to make a 3x5 "card". Information adapted from OEM sources; not verified nor endorsed. User is advised to verify any content herein with manufacturers documentation.

ZEROING AID GRID: 2 MOA @ 25 YD=0.52"



## Holosun 509T X2

**Power ON:** Shake sight or press either brightness button

**Power OFF:** Press "+" and "-" simultaneously to turn power and motion sensor off (**Shake Awake™** (\*) is disabled)

Press "-" 3 sec, to switch from Circle+Dot(\*), Dot, and Circle

Press "+" 3 sec, to switch from Automatic(\*) to Manual to Lockout


**Solar Fail Safe™** provides dual power (solar and internal)

\*default

GENERAL PURPOSE GRID: 1.00"

Layout / Design llando88@gmail.com 2021. Unlimited copy and distribution permitted. **REV 9**

## Holosun 509T X2



### 10 daylight and 2 NV brightness settings.

Your selected Manual Brightness is ☐ clicks down from FULL BRIGHT. Battery is a **CR1632**. Reticle blinks if the battery is low (2.2 V).

Insert new battery "+" side **DOWN**.

**Adjustment screws** move center of impact U/D, R/L. 1click = 1MOA

**25 yds:** 32MOA=8.4" 2MOA=0.5" **10 yds:** 32MOA=3.4" 2MOA=0.2"

6-32 T10 Plate screws=15 in-lbs+blue threadlocker; clamp=20 in lbs

Clean with lens cleaner, **NO** alcohol or acetone

Footprint: RMR / Titanium body / 1 Meter IPX7 waterproof fogproof

[www.holosun.com](http://www.holosun.com) [warranty@holosun.com](mailto:warranty@holosun.com) (909) 594-2888

Instructions: Cut on dotted lines / fold to make a 3x5 "card". Information adapted from OEM sources; not verified nor endorsed. User is advised to verify any content herein with manufacturers documentation.

ZEROING AID GRID: 2 MOA @ 25 YD=0.52"