



## Trijicon<sup>(R)</sup> RMR Quick Reference Card 1/2

**Power on:** Press either of the buttons to turn the unit on and the unit wakes up in automatic mode.


**Press both buttons** simultaneously for less than 3 seconds and release to enter automatic mode. Press both buttons simultaneously and hold them for 3 seconds **to turn the unit off.**

Press and release the **plus button** to increase brightness and to enter manual mode. Press and release the **minus button** to decrease brightness and to enter manual mode.

RMR will Automatically adjust aiming dot to ambient lighting conditions after **16.5 hours**

qrc\_rmr\_v2.odg

20210529



## Trijicon<sup>(R)</sup> RMR Quick Reference Card 2/2

Brightness settings for **manual illumination** control has 8 settings.

**Automatic mode** will cover the range of settings 3-7 depending on current ambient condition.

RMR uses a CR2032 3V DC Lithium battery.

Install new battery with negative side "-" facing down.

The aiming dot will become dimmer as the battery gets low.

Turn **Adjustment screws** in the direction to move impacts, 1click=1MOA

**25 yds:** 6.5MOA=1.7" / 3.25MOA=0.9"

**10 yds:** 6.5MOA=0.7", 3.35MOA=0.3"

Torque Optic Screws until is seats, then secure.

Clean with fresh water and clean cloth, not alcohol, TCE or acetone

Trijicon Customer Service: [www.trijicon.com](http://www.trijicon.com) (800) 338-0563

qrc\_rmr\_v2.odg

20210529