



Swampfox Liberty & Justice Quick Reference Card

Power on: Use Shake N' Wake motion sensing illumination to turn optic on. After about four minutes without sensing any motion, illumination will shut off.

Power off: Press and hold the brightness down button 3 seconds.

Choose between **10 levels of brightness** using up/down buttons

REVISION 8

1 IN

Instructions: Print actual size, cut out, fold 1X to produce a 3"x5" card for pocket or range bag. 1" and 1 cm grids provided to estimate group sizes.

Swampfox Liberty & Justice Quick Reference Card



JUSTICE 1X27

To install or replace the CR1632 battery, remove the battery cover Torx T10 screw. Replace the battery cover and tighten until snug. Do not over tighten.

Turn **Adjustment screws** in the direction to move impacts, 1click=1MOA
Max 45 MOA

10 yds: 3 MOA = 0.3" **25 yds:** 3 MOA = 0.8"

Footprint: RMR

Swampfox Customer Service: (720) 389-6719

DISCLAIMER: Information adapted from OEM sources, but is not verified nor endorsed. 1 CM
User is advised to verify any content herein with manufacturers documentation.