

Trijicon® RMR® Quick Reference Card

Power on: Press either button to turn on. RMR wakes up in automatic mode.

Press both buttons simultaneously for less than 3 seconds and release to enter automatic mode. Press both buttons simultaneously and hold them for 3 seconds **to turn the unit off**.

Press and release the **plus button** to increase brightness and enter manual mode. Press and release the **minus button** to decrease brightness and enter manual mode.

Aiming dot automatically adjusts to ambient lighting after 16.5 hours.

REVISION 8

1 IN

Instructions: Print actual size, cut out, fold 1X to produce a 3"x5" card for pocket or range bag.

1" and 1 cm grids provided to estimate group sizes.

Trijicon® RMR® Quick Reference Card





Manual illumination control has 8 brightness settings.

Automatic mode covers settings 3-7 depending on ambient light.

Battery is a CR2032 3V DC Lithium. Install negative side "-" facing down.

The aiming dot will become dimmer as the battery gets low.

Turn Adjustment screws in the direction to move impacts, 1click=1MOA

25 yds: 6.5 MOA=1.7"/ 3.25 MOA=0.9" **10** yds: 6.5 MOA=0.7", 3.25 MOA=0.3"

Torque Optic Screws until seated, then secure.

Clean with fresh water and clean cloth, not alcohol, TCE or acetone

Trijicon Customer Service: www.trijicon.com (800) 338-0563

DISCLAIMER: Information adapted from OEM sources, but is not verified nor endorsed. 1 CM
User is advised to verify any content herein with manufacturers documentation.