



## Sig Sauer® ROMEOZero Quick Reference Card

**Power ON:** Move the sight, or momentarily press either the UP or DN brightness adjustment button

**Power OFF:** press and hold either the UP or DN brightness adjustment button for 2 seconds.

After 2 minutes of inactivity (no movement), the sight will enter its **power saving mode** and automatically shut off.

Dot will flash 5 times at the highest or lowest brightness settings.

To disable **MOTAC™**(\*), press and hold both buttons for 3 seconds. The sight will flash the LED one time to signify MOTAC™ is disabled. To re-enable MOTAC™ simply repeat the process.


\* default

**REVISION 8**


1 IN

**Instructions:** Print actual size, cut out, fold 1X to produce a 3"x5" card for pocket or range bag.  
1" and 1 cm grids provided to estimate group sizes.

## Sig Sauer® ROMEOZero Quick Reference Card



3 MOA Red Dot



6 MOA Red Dot

Select from **8 Daytime brightness settings** using UP or DN buttons

To change the **CR 1632** battery, remove the sight. Install the new battery positive (+) side facing out (down). Reinstall the sight.

Torque mounting screws to 9 in-lbs.

To **raise your point of impact**, use the included .050" Allen wrench to turn the elevation screw clockwise. To lower, turn counter-clockwise.

To **move your point of impact left**, turn the windage screw clockwise. To move right, turn counter-clockwise.

**Footprint:** Shield RMS-c

Sig Sauer CS: (603) 610-3000

[www.sigsauer.com](http://www.sigsauer.com)

**DISCLAIMER:** Information adapted from OEM sources, but is not verified nor endorsed.  
User is advised to verify any content herein with manufacturers documentation.

1 CM