



Sig Sauer® ROME01PRO Quick Reference Card

Power ON: Move the sight, or momentarily press either the UP or DN brightness adjustment button

Power OFF: press and hold either the UP or DN brightness adjustment button for 2 seconds.

After 2 minutes of inactivity (no movement), the sight will enter its **power saving mode** and automatically shut off.

Dot will flash 5 times at the highest or lowest brightness settings.

To disable **MOTAC™**(*), press and hold both buttons for 3 seconds. The sight will flash the LED one time to signify MOTAC™ is disabled. To re-enable MOTAC™ simply repeat the process.


* default

REVISION 8


1 IN

Instructions: Print actual size, cut out, fold 1X to produce a 3"x5" card for pocket or range bag.
1" and 1 cm grids provided to estimate group sizes.

Sig Sauer® ROME01PRO Quick Reference Card



3 MOA Red Dot



6 MOA Red Dot

Select from **10 Daytime/2 NV brightness settings** using UP or DN buttons

The **CR 1632** battery is located beneath the Battery Cap that is accessed from the top of the sight. Remove the Battery Cap by turning "left" (counter-clockwise) using the large flat tip end of the Adjustment Tool.

Install the battery with the positive (+) side facing up. Check the battery cap approximately every 500 rounds to ensure it is still tight.

Turn **Adjustment screws** in the direction to move impacts, 1click=1MOA

25 yds: 6MOA=1.6"/ 3MOA=0.8" **10 yds:** 6MOA=0.6", 3MOA=0.3"

Sig Sauer CS: (603) 610-3000

www.sigsauer.com

DISCLAIMER: Information adapted from OEM sources, but is not verified nor endorsed.
User is advised to verify any content herein with manufacturers documentation.

1 CM